

BosSTRAP

Attaching the G3 Tail to a Camera using a Strap Keeper

1. Remove the Tail strap from the body strap by working the vinyl safety sleeve off the closed cam buckle.



2. Lift the cam buckle lever. Leave the 3/8" strap keeper on the G3 Tail.

3. Slide the free end of the G3 Tail down through the camera strap lug (or strap ring). Thread the free end back through the strap keeper.



4. Position the cam buckle about 2" from the camera strap lug. Push the small nylon strap keeper near the camera lug. Insert the free end of the strap through the metal slide on the sling strap and under the open cam buckle lever. Lock down the cam buckle lever.

5. Push the safety vinyl sleeve back partially covering the closed cam buckle. The vinyl sleeve only needs to cover the end of the closed cam buckle lever.

