

## Attaching a Side Release Quick Disconnect Tail to a Camera

The BosStrap Side Slide Camera Tail is a two-piece strap that uses a Side Release Quick Disconnect to separate the camera from the strap. The female side of the Quick Disconnect is attached to and remains with the camera. The following photos show how to attach the female side of the Side Release Quick Disconnect to the camera.

