

BosStrap Generation 3 and Generation 3 LT Installation and Fitting Instructions

Initial Fit Adjustment of the BosStrap Sling Strap

The BosStrap body strap should be approximately adjusted to fit you before the G3 Tail is attached to the camera. Begin by opening the BosStrap body strap to a larger than needed loop. Put your head and right arm through the BosStrap. The BosStrap should be over your left shoulder, across your chest under your right arm with the nylon fittings at your back. Leave the free end of the strap dangling down until the final adjustment is made. The BosStrap is on correctly when the BosStrap logo on the front is properly oriented as shown in the photograph at right. The BosStrap length should be adjusted so that the bottom of the metal slide plate is at your right side, a few inches above your hip.



Attaching the Generation 3 Tail to your Camera



1. The G3 Tail as shipped is attached to the metal glide fitting.



2. Work the vinyl sleeve back to access the cam lock. On new products, the sleeve tends to be a little stiff. This will relax in time.



3. Open the cam lock and release the G3 Tail from the metal slide. It is easier to open the cam buckle lever by pulling on the 3/8" strap end, rather than using a finger nail to open it.



4. Remove the small triglide on the G3 Tail. Leave the vinyl sleeve on the G3 Tail.



5. Rethread the end of the G3 Tail through the triglide as shown.



6. Thread the G3 Tail through the left camera strap lug from top.



9. Thread the Generation 3 Tail under the cam lock lever and through the sleeve. Allow about 1" of webbing to go beyond the cam buckle. When you next open the cam buckle, pulling on this end will make it easier to open.



7. Continue threading the G3 Tail back through the small triglide as shown in the figure at left. Snug up as shown in Fig 10 leaving about 2" between the camera lug and the narrow end of the cam buckle, Fig 11.



10. Snap the cam lock closed. You will hear and feel a secure snap.



8. Lay flat the body strap with the Bos Strap logo facing up. Insert the Generation 3 Tail end from under the metal slide as shown in Fig 8 .



11. Push the vinyl sleeve on the cam lock to secure the cam lever. The sleeve is designed not to completely cover the closed cam buckle.

Final Adjustments

Now, put on the Bos Strap with the camera and lens attached and adjust the Bos Strap so that the camera is at a comfortable location by your right hip and your hand falls naturally on where you grip the camera. After you fine tune the Bos Strap length, extra slack beyond the buckle can be neatly secured with the included triglide. Small adjustments to the G3 Tail length and the Bos Strap can make big differences in comfort. When not using the camera, turn it so the lens points down and backward for minimal camera movement when walking.